



EZ X STAND



- Loosen jam lock and lower the center bar.
- Lay stand flat on it's back.
- Unroll banner, face up, on top of banner stand.
- Secure grommetted sign face to hooks.
- Raise center bar till the sign face is tensioned.
- Tighten jam lock to secure center pole.
- Set sign upright adjusting the legs to a secure position.
- Make any last minute adjustments to tension and make sure Jam Lock is securely locked.

Jam Lock



CAUTION!

- Take your time assembling this sign.
- DO NOT force the plastic parts.
- DO NOT try to assemble the sign with the center bar fully extended.
- Banner should be loose when first hooked to the stand.
- Grommets are tight fitting on the hooks.
- DO NOT FORCE the grommets over the hooks. Rock them gently onto hooks.